

WATCHDOG® DISPOSABLE BREATHER INSTALLATION PROCEDURE

1. Remove WATCHDOG® Breather from plastic bag.
2. Remove white cap from the standpipe at the bottom of the Breather.
3. Remove air seal from around the top of the Breather by pulling down on the tab.
4. Mount the Breather on a tank or reservoir using the adapter best suited to the application. The available selection of adapters is shown on the reverse side of this procedure.


The WATCHDOG® Breather and adapter replace the standard breather cap.

The adapter does not need to be changed when installing a replacement Breather.

WATCHDOG® Disposable Breathers are rated for 35 SCFM airflow. This is the equivalent of 260 gallons per minute of fluid volume change within the reservoir.

LIMITED WARRANTY: The Manufacturer makes the Limited Express Warranty that, at the date of delivery, its goods shall be free from defects in The Manufacturer's materials and workmanship and shall meet the express written statements of quality, if any, made by The Manufacturer. in connection with the sale of the goods. Other than such Limited Express Warranty, there are no express warranties made with respect to the sale of goods and all implied warranties existing under the law are expressly disclaimed and negated, particularly, The Manufacturer **NEGATES AND DISCLAIMS THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.** All other liability, either in contract or tort, including, without limitation, strict liability found in Section 402A of Restatement of Torts or otherwise is negated and disclaimed. The sole remedy for The Manufacturer's breach of such Limited Express Warranty shall be a refund of the purchase price of its goods, and The Manufacturer. shall have no responsibility for incidental or consequential damages sustained as a result of the use of the goods, whether sustained to the goods themselves or to other property. The typical characteristics of the data listed are subject to usual manufacturing variations.

ADAPTERS FOR INSTALLING WATCHDOG® DISPOSABLE BREATHERS



These adapters are designed to satisfy most applications for breathers installed on new reservoir or "in-the-field" applications. They do not need to be changed when installing a replacement WATCHDOG® Breather. The adapters are designed to accommodate reservoirs that currently use breather caps, spin-on filter cartridges, or other breathers.